

## **AVF Motion Air Mouse** (Cursor Reconfiguration) – via PC

### **Step 1 – Prepare**

Turn on = **Air Mouse** by pressing the **Android icon** (Center)

Press on = **Up, Down,** and **Enter button** in **sequence** at the same time.

Release = all **3 buttons** after 3 seconds, you'll now find the **lights** on Air Mouse **starts blinking rapidly**.

### **Step 2 – Reset**

Plug in = **USB Dongle** (Air Mouse Transmitter) into your **PC's** USB port, it should **stop** the **light blinking** on the Air Mouse.

Turn off = **Air Mouse** by pressing the **Android icon** again.

### **Step 3 – Reconfigure**

Press on = **Left & G buttons** in **sequence** at the same time, you'll see the **light** on Air Mouse **turns up**.

Release = all **2 buttons** after 3 seconds as well, and you shall see the light's **off** shortly after you released the buttons.

Congratulation, your **Air Mouse** has been **reconfigured**. Thank You.